Portable Video Speaker Phone

User's Guide

Version 1.0

Introduction and Features



System Requirement

- Pentium 4/Celeron, AMD 1GHz or faster processor, minimum 256MB RAM
- Microsoft Windows XP/Vista series
- USB compatible

Package Contents

- Portable Speaker Phone with USB cable
- One Y-USB power cable
- Setup Installation and Software CD
- User Guide

Getting started

You will need to install the drivers and application software in the CD before connecting the unit.

Do not connect your new unit to your computer before installing the drivers.

Tips

If you accidentally begin installation with your unit connected and the Add **New Hardware Wizard** or **Found New Hardware Wizard** dialog box appears, click the **Cancel** tab.

Installation Steps:

1. Insert the Installation CD into your CD-ROM drive. The installation program should start automatically. Follow the on-screen instructions to finish up the installation.

2. Click the "Video Speaker Phone Driver" icon to install device driver.

3. Click the "ArcSoft WebCam Companion" icon and follow the instructions.



4. Select "User Guide" to know more about detail setting.



5. After you installed the device driver, please restart your system.

Settings

Audio setting

1. To use this device, you will need to have Microsoft Windows XP/Vista installed on your computer.
2. To use this device for internet communication, you must have a broadband internet connection and applicable software which supports audio and/or video calls (such as Skype) installed properly on your computer.
3. You can verify and adjust the audio settings by following these steps:
   i. In the Windows Start menu, go to **Control Panel**
   ii. Select the **Sound and Audio device** icon
   iii. In the **Audio** tab, click on the **volume** button, a **Volume Control** screen appears
   iv. You can adjust the volume of the microphone and speaker by using the control buttons located at the front of the unit directly.

Tips

1. If you cannot hear any sound from the unit, close all your current applications. Select ***Start → Control Panel ->Sounds and Audio devices -> Audio ->*** then select "C-Media USB audio Device" as the *default Windows Audio device* for both sound playback and sound recording.

2. To check volume settings or when there is no sound from the unit, repeat step 1) above to select ***Sounds and Audio devices -> Volume*** -> make sure that "Mute" check box is not checked. When you select Advanced button, a "***Volume Control***" screen pops-up. You may adjust volume up or down accordingly.
3. To check microphone settings, bring up the "Volume Control" screen, click Advanced button and select ***Options -> Properties -> Adjust volume for -> Recording***.
4. Make sure "***Recording***" is checked and click OK, there will be a new Advanced button. Select "***Options -> "Advanced Controls -> Other Controls***". Make sure that "**AGC**" is not checked.
5. If your unit's LED changes from "blue" to "red" color, it is in mute recording state. Press the ***"Microphone Mute"*** button on your unit once and the LED will change back to "blue" again.

Video setting

Snap Size Adjustment

1. In order to run "AMCAP," please select "***Start → Program →CamMaestro 4.00 DU PC Camera → AMCAP***".



Tips

If you cannot see any videos, please select "Device" and check the "**CamMaestro 4.00 DU PC Camera**".

2. When the "Properties" dialogue box pops up, please select "Output Size" and choose the size you need. There are five selections as below:

Default: 640 x 480
160 x 120;
176 x 144;
320 x 240;
352 x 288;
640 x 480



Useful information

1. Connect your Speaker Phone directly to the available USB port. Using an extended cable or USB hub device is not recommended.
2. If the system prompts you insufficient power, remove any USB device not in use and plug SP110 again. Follow these steps:
   i. Plug in both ends of the USB male connectors of the Y-USB power cable to two available USB ports of your computer.
   ii. Next, connect the free end of your unit's USB male connector to the USB female connector of the Y-USB power cable.
   iii. Your new unit will now be automatically detected by Windows operating system.
3. For stereo sound of audio playback or private conversation, stereo headphones can be plugged into 3.5mm stereo headphone jack located on the side of the unit.

FCC Certification

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference, received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency, energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Consult the dealer or an experienced radio/TV technician for help.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FOR EUROPE

CE "The unit is in conformity with the EMC directive and low-voltage directive."

Disclaimer

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any other commercial damage, including but not limited to special, incidental, consequential, or other damages. No part of this document may be reproduced or transmitted in any form by any means, electronic or mechanical, including photocopying, recording or information recording and retrieval systems without the express written permission of the manufacturer.

WEEE LOGO

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

All trademarks and logos belong to their respective owners.

3100553680 Version 1.0 July 2007

Configuration système requise

- Pentium 4/Celeron ou AMD 1GHz ou processeur plus rapide, 256MB RAM recommandés.
- Compatible Microsoft Windows XP/Vista

Étapes d'installation :

1. Insérez de CD d'installation le dans lecteur le CD-ROM. Le programme démarre d'installation automatiquement. Suivez les instructions à l'écran pour terminer l'installation.

2. Cliquez sur l'icône “Video Speaker Phone Driver (Pilote du haut-parleur téléphonique vidéo)” pour installer le pilote du périphérique.



3. Cliquez sur l'icône “ArcSoft WebCam Companion (Compagnon Webcam ArcSoft)” et suivez les instructions.

4. Sélectionnez “User Guide (Guide d'utilisation)” pour en savoir plus sur les réglages détaillés.



French

Requisiti del sistema

- Processore Pentium 4/Celeron ed AMD 1GHz o più potente; 256MB di RAM raccomandati.
- Compatibile Windows XP/Vista

Fasi d'installazione:

1. Inserire il CD d'installazione nell'unità CD-ROM. Il programma d’installazione dovrebbe avviarsi automaticamente. Seguire le istruzioni su schermo per completare l'installazione.

2. Fare clic sull’icona “Video Speaker Phone Driver” (Driver video vivavoce) per installare il driver.



3. Fare clic sull'icona “ArcSoft WebCam Companion” e seguire le istruzioni.



4. Selezionare “User Guide” (Guida dell’utente) per altri dettagli sulle impostazioni.



Italian

Requisitos do sistema

- Processador Pentium 4/Celeron e AMD de 1 GHz ou acima, 256 MB de RAM recomendado.
- Compatível com o Microsoft Windows XP/Vista

Instalação:

1. Introduza o CD de instalação na unidade de CD-ROM. O programa de instalação inicia automaticamente. Siga as instruções no ecrã para concluir a instalação.

2. Clique no ícone “Video Speaker Phone Driver” (Controlador do altifalante) para instalar o controlador do dispositivo.



3. Clique no ícone “ArcSoft WebCam Companion” e siga as instruções.

4. Seleccione a opção “User Guide” (Guia do utilizador) para obter mais informações.



Portugese

Systemanforderungen

- Pentium 4/Celeron und AMD 1GHz oder noch schnellere CPU, 256MB RAM empfohlen.
- Microsoft Windows XP-kompatibel/Vista

Installationsschritte:

1. Legen Sie die Installations-CD in Ihr optisches Laufwerk ein. Das Installationsprogramm wird automatisch gestartet. Folgen Sie den Bildschirmanweisungen, um die Installation fertig zu stellen.

2. Klicken Sie auf das "Video Speaker Phone Driver [Video-Lautsprechertelefontreiber]"-Symbol, um den Gerätetreiber zu installieren.



3. Klicken Sie auf das "ArcSoft WebCam Companion"-Symbol und folgen dann den Anweisungen.



4. Wählen Sie "User Guide [Bedienungsanleitung]" für Details zur Einstellung.



German

Requisitos del Sistema

- Recomendado Pentium 4/Celeron y procesador AMD 1GHz ó superior, 256MB RAM.
- Compatible con Microsoft Windows XP/Vista

Pasos de la Instalación:

1. Inserte el CD de Instalación en su unidad CD-ROM. El programa de Instalación debería comenzar automáticamente. Siga las instrucciones de la pantalla para finalizar la instalación.

2. Haga clic en el icono “Video Speaker Phone Driver” (Controlador de Vídeo del Teléfono Altavoz) para instalar el controlador del dispositivo.

3. Haga clic en el icono “ArcSoft WebCam Companion” y siga las instrucciones.



4. Selecciones “User Guide” (Guía del Usuario) para saber más sobre los detalles de la configuración.

Spanish

Systeemvereisten

- Pentium 4/Celeron en AMD 1GHz of snellere processor, 256MB RAM aanbevolen.
- Compatibel met Microsoft Windows XP/Vista

Installatiestappen:

1. Plaats de installatie-cd in het cd-romstation. Het installatieprogramma zou automatisch moeten starten. Volg de richtlijnen op het scherm om de installatie te voltooien.

2. Klik op het pictogram “Video Speaker Phone Driver” (Stuurprogramma videoluidsprekertelefoon) om het apparaatstuurprogramma te installeren.



3. Klik op het pictogram “ArcSoft WebCam Companion” en volg de instructies.

4. Selecteer "User guide" (Gebruikershandleiding) voor meer details over de instellingen.



Dutch